

VIBRATORY RAMMER

**CEDST02
MANUAL**



CONTENT

I .	INTRODUCTION	
II	- 2 -	
SAFETY & SYMBOLS		SYMBOLS
HAZARDS SYMBOLS	- 2 -	- 3 - 2.3
GENERAL SAFETY	- 5 -	2.4
TRANSPORTING.....	- 7 -	2.5
MAINTENANCE	- 7 -	2.6
EMERGENCIES	- 7 -	.
GENERAL INFORMATION	- 8 -	
III		
3.1 DEFINITION	- 8 -	
3.2 CONSTRUCTION	- 8 -	
3.3 CONTROLS.....	- 8 -	
3.4 BASIC ENGINE	- 10 -	
IV. OPERATION	- 11 -	
4.1 CHECK SPRING CYLINDER OIL BATH	- 11 -	
4.2 CHECK ENGINE	- 12 -	
4.3 INSPECTION	- 12 -	
4.4 START	- 13 -	
4.5 STOP ENGINE	- 16 -	
V .MAINTENANCE	- 17 -	
VI. TROUBLESHOOTING	- 19 -	
6.1 ENGINE TROUBLESHOOTING	- 19 -	
6.2 RAMMER TROUBLESHOOTING	- 20 -	
VII. REPLACEMENT PARTS LIST	- 21 -	
7.1 GUIDE CYLINDER AND FOOT ASSY	- 21 -	
7.2 CRANKCASE AND ENGINE ASSY	- 23 -	
7.3 TANK AND HANDLE ASSY	- 25 -	

WARNING To reduce the risk of injury, all operators and maintenance personnel must read and understand these instructions before operating, changing accessories, or performing maintenance on power equipment. All possible situations cannot be covered in these instructions. Care must be exercised by everyone using, maintaining or working near this equipment.


CAUTION


NO OIL IN ENGINE
 Fill the engine with oil to the correct level before starting the engine.

ДВИГАТЕЛЬ ПОСТАВЛЯЕТСЯ БЕЗ МАСЛА
 Перед запуском проверьте и заполните до требуемого уровня.

MOTOR SIN ACEITE
 Agregue aceite al motor al nivel correcto antes de encenderlo.

MOTOR SEM ÓLEO
 Adicione óleo ao nível correto antes de ligar o motor.

I . INTRODUCTION

Thank you for your selection of our equipment.

We have taken care in the design, manufacture and testing of this product. Should service or spare parts be required, prompt and efficient service is available from our branches.

General Safety instructions for the Operation of Power Equipment. Our factory's goal is to produce power equipment that helps the operator work safely and efficiently. The most important safety device for this or any tool is the operator. Care and good judgment are the best protection against injury. All possible hazards cannot be covered here, but we have tried to highlight some of the important items, individuals should look for and obey Caution, Warning and Danger signs placed on equipment, and displayed in the workplace. Operators should read and follow safety instructions packed with each product.

Learn how each machine works. Even if you have previously used similar machines, carefully check out each machine before you use it .Get the "feel" of it and know its capabilities, limitations, potential hazards, how it operates, and how it stops. We has no duty if person don't operate as instruction said.

II .SAFETY&ALERT SYMBOLS

FOR YOUR SAFETY AND THE SAFETY OF OTHERS!

Safety precautions should be followed all the time when operating this equipment. Failure to read and understand the Safety Messages and Operating Instructions could result in injury to yourself and others.



This Operating Instructions has been developed to provide complete instructions for the safe and efficient operation of the vibratory rammer. Refer to the engine manufactures instructions for data relative to its safe operation.

Before using this rammer, ensure that the operating individual has read and understood all instructions in this manual.

2.1 SAFETY SYMBOLS

The three (3) Safety Messages shown below will inform you about potential hazards that could injure you or others. The three Safety Messages specifically address the level of exposure to the operator, and are preceded by one of three words: DANGER, WARNING and CAUTION.



You **WILL** be **KILLED** or **SERIOUSLY INJURED** if you **DO NOT** follow these directions.



You **CAN** be **KILLED** or **SERIOUSLY INJURED** if you **DO NOT** follow these directions.



You **CAN** be **INJURED** if you **DO NOT** follow these directions.

2.2 HAZARDS SYMBOLS

Potential hazards associated with the operation of a vibratory rammer will be referenced with Hazard Symbols which appear throughout this manual, and will be referenced in conjunction with Safety Message Alert Symbols.



Lethal Exhaust Gas Hazards

Engine Exhaust gases contain poisonous carbon monoxide. This gas is colorless and odorless, and can cause death if inhaled. **NEVER** operate this equipment in a confined area or enclosed structure that does not provide ample free flow air.



Explosive Fuel Hazards

Gasoline is extremely flammable, and its vapors can cause an explosion if ignited. **DO NOT** start the engine near spilled fuel or combustible fluids. **DO NOT** fill the fuel tank while the engine is running or hot. **DO NOT** overfill tank, since spilled fuel could ignite if it comes into contact with hot engine parts or sparks from the ignition system. Store fuel in approved containers, in well-ventilated areas and be away from sparks and flames.



Burn Hazards

Engine components can generate extreme heat. To prevent burns, **DO NOT** touch these areas while the engine is running or immediately after operations. Never operate the engine with heat shields or heat guards removed.





WARNING

Respiratory Hazards

ALWAYS wear approved respiratory protection when required.



CAUTION

Rotating Parts Hazards

NEVER operate equipment with covers, or guards removed. Keep fingers, hands, hair and clothing away from all moving parts to prevent injury.



CAUTION

Accidental Starting Hazards

ALWAYS place the ON/OFF switch in the OFF position when the rammer is not in use.



CAUTION

Eye and Hearing Hazards

ALWAYS wear approved eye and hearing protection.



CAUTION


Equipment Damage Hazards

Other important messages are provided throughout this manual to help prevent damage to your light tower, other property, or the surrounding environment.



DANGER

Refueling Hazard





DANGER

Read this manual

Failure to follow instructions in this manual may lead to serious injury or even death! This equipment is to be operated by trained and qualified personnel only! This equipment is for industrial use only.

2.3 GENERAL SAFETY



DO NOT operate or service this equipment before reading this entire manual.



This equipment should not be operated by persons under 18 years of age.



NEVER operate this equipment without proper protective clothing, shatterproof glasses, steel-toed boots and other protective devices required by the job.



NEVER operate this equipment when not feeling well due to fatigue, illness or taking medicine.



NEVER operate this equipment under the influence of drugs or alcohol.



ALWAYS wear proper respiratory (mask), hearing and eye protection equipment when operating the rammer.



Whenever necessary, replace nameplate, operation and safety decals when they become difficult read.



Manufacturer does not assume responsibility for any accident due to equipment modifications.



NEVER use accessories or attachments, which are not recommended for this equipment. Damage to the equipment and/or injury to user may result.



NEVER touch the hot exhaust manifold, muffler or cylinder. Allow these parts to cool before servicing engine or rammer.



- ☐ High Temperatures – Allow the engine to cool before adding fuel or performing service and maintenance functions. Contact with hot components can cause serious burns. The engine section of this rammer requires an adequate free flow of cooling air. NEVER operate the rammer in any enclosed or narrow area where free flow of the air is restricted it will cause serious damage to the rammer or engine and may cause injury to people. Remember the rammer's engine gives off DEADLY carbon monoxide gas.



- ☐ ALWAYS refuel in a well-ventilated area, away from sparks and open flames.
- ☐ ALWAYS use extreme caution when working with flammable liquids. When refueling, stop the engine and allow it cool.
- ☐ NEVER operate the rammer in an explosive atmosphere or near combustible materials. An explosion or fire could result causing severe bodily harm or even death.
- ☐ DO NOT smoke around or near the machine. Fire or explosion could result from fuel vapors, or if fuel is spilled on a hot engine.
- ☐ Topping-off to filter port is dangerous, as it tends to spill fuel.
- ☐ Stop the engine when leaving the rammer unattended.
- ☐ Maintain this equipment in a safe operating condition at all times.
- ☐ ALWAYS stop the engine before servicing, adding fuel and oil.
- ☐ NEVER run engine without air filter. Severe engine may occur.
- ☐ ALWAYS service air cleaner frequently to prevent carburetor malfunctions.
- ☐ ALWAYS check the machine for loosened threads or bolts before starting.
- ☐ ALWAYS be sure the operator is familiar with proper safety precautions and operations techniques before using rammer.
- ☐ ALWAYS store equipment properly when it is not being used. Equipment should be stored in a clean, dry location out of the reach of children.
- ☐ DO NOT operate this equipment unless all guards and safety devices are attached and in place.
- ☐ CAUTION must be exercised while servicing this equipment.
- ☐ Keep all inexperienced and unauthorized people away from the equipment at all times.
- ☐ Unauthorized equipment modifications will void all warranties.
- ☐ NEVER pour or spray water over the engine.
- ☐ Test the engine ON/OFF switch before operating. The purpose of this switch is to shut down the engine of the rammer.
- ☐ Refer to the Engine User's Manual for engine technical questions or information recommended for the equipment.

2.4 TRANSPORTING



ALWAYS shut down engine before transporting.

- ☐ Tighten fuel tank cap securely and close fuel cock to prevent fuel from spilling.
- ☐ Drain fuel when transporting rammer over long distances or bad roads.
- ☐ When placing the rammer inside a truck-bed for transport, always tie-down the rammer.

2.5 MAINTENANCE



NEVER lubricate components or attempt service on a running rammer.

- ☐ ALWAYS allow the rammer a proper amount of time to cool before servicing.
- ☐ Keep the rammer in proper running condition.
- ☐ Fix damage to the rammer immediately and always replace broken parts.
- ☐ Dispose of hazardous waste properly. Examples of potentially hazardous waste are used motor oil, fuel and fuel filters.
- ☐ DO NOT use wooden or plastic containers to dispose of hazardous waste.

2.6 EMERGENCIES



ALWAYS know the location of the nearest fire extinguisher and first aid kit.



- ☐ In emergencies always know the location of the nearest phone or keep a phone on the job site. Also know the phone numbers of the nearest ambulance, doctor and fire department. This information will be invaluable in the case of an emergency.



III. GENERAL INFORMATION

3.1 DEFINITION

The vibratory rammer is a powerful compacting tool capable of applying a tremendous force in consecutive impacts to a soil surface. Its applications include soil compacting for road, embankments and reservoirs as well as backfilling for gas pipelines, water pipelines and cable installation work.

Circular motion is converted to create impact force. The vibratory rammer develops a powerful compacting force at the foot of the rammer. To maintain optimum performance, proper operation and service are essential.

3.2 CONSTRUCTION

The engine of the rammer is equipped with a governor which automatically increases the engine speed to engage the centrifugal clutch.

3.3 CONTROLS

Before starting the vibratory rammer identify and understand the function of the controls.




Fig 1

Fig 1 shows the location of the controls and components for the vibratory rammer.

The function of each control is described below:

- 1 Throttle Lever – Controls engine speed and the tamping action of the rammer. Engine
- . Stop Switch –Controls the starting and stopping of the engine. Switch must be in the
- 2 “ON” position when starting the engine. Choke Lever – Used when starting the engine.
3. Normally used in cold weather conditions. In cold weather turn the choke lever to the
- fully closed position, in warm weather set choke lever half way or completely open. Fuel
- Shut-Off Valve – Supplies fuel from the fuel tank to the engine. To begin fuel flow move
4. the fuel shut-off valve downward. Pre-Cleaner – Pre-cleans (first stage) dirt and other
- debris from entering the engine. Foot – Laminated wood with tempered steel plate for
- 7 superior shock absorption. Oil Level Sight Glass – Indicates the level of oil in the oil bath
- . reservoir.
- 8
- 10.Recoil Starting Handle – Used when starting the engine. Pull starter handle sharply and
- 9 quickly, then return starter handle to starter case before releasing.
- 11.Fuel Tank/Cap – Poly fuel tank to avoid rust and corrosion, remove this cap to add
- gasoline. 12.Engine Air Cleaner – Prevents dirt (second stage) and other debris from entering
- the engine.
13. Oil Reservoir – Reservoir for oil bath.
- 14.Handle – To operate rammer, grip handle assembly firmly on both sides.
- 15.Muffler – Used to reduce noise and emissions.
- 16.Spark Plug – Provides spark to the ignition system, replace with engine manufacturers
- recommended type spark plug.
- 17.Nameplate – Displays information regarding the rammer.

3.4 BASIC ENGINE




Fig 1A

The engine (Fig 1A) must be checked for proper lubrication and filled with fuel prior to operation. Refer to the Engine User's Manual for instructions.

1. Secondary Air Cleaner – Prevents dirt and other debris from entering the fuel system. Remove wing-nut on top of air filter canister to gain access to filter element.
2. Choke Lever – Used when starting the engine. Normally used in cold weather conditions. In cold weather turn the choke lever to the fully closed position, in warm weather set choke lever half way or completely open.
3. Spark Plug – Provides spark to the ignition system. Set spark plug gap to 0.6–0.7 mm (0.024–0.028 inch). Clean spark plug once a week.
4. Muffler – Used to reduce noise and emissions.



WARNING



Engine components can generate extreme heat. To prevent burns, **DO NOT** touch these areas while the engine is running or immediately after operating. **NEVER** operate the engine with the muffler removed.

1. Recoil Starter (pull rope) – Manual-starting method. Pull the starter grip until resistance is felt, then pull briskly and smoothly.
2. Engine ON/OFF Switch – Controls the starting and stopping of the engine. Switch must be in the “ON” position when starting the engine.



NOTE

Operate the engine without an air filter, with a damaged air filter, or a filter in need of replacement will allow dirt to enter the engine, causing rapid engine wear.

IV. OPERATION

This section is intended to assist the operator with the initial start-up of the vibratory rammer. It's extremely important that this section should be read carefully before attempting to operate the rammer.

DO NOT use your rammer until this section is thoroughly understood.



CAUTION

Read Manual

Failure to understand the operation of the vibratory rammer could result in severe damage to the trowel or personal injury.

4.1 CHECK SPRING CYLINDER OIL BATH

This unit uses an oil bath lubrication system. Perform the following:

1. Check the oil level through the oil level sight glass (Figure 2) at the rear of the tamper foot.




Fig 2

2. If oil is not visible, add Mobil ISO VG46 or other oil with same standard into the oil fill plug opening (Fig 2). The bath contains approximately 1000 cc..



NOTE

The oil level should be kept at the half way point of the sight glass.

4.2 CHECK ENGINE

1. Fill the fuel tank (Fig 3) with unleaded gasoline. At the same time, check the engine oil and make it a habit to replenish it often.




Fig 3




Fig 4

2. Low levels of oil may result in engine seizure due to high levels of consumption during operations.
3. Check the engine oil level (Fig 4) and if the engine oil level is low, it should be refilled. Use the proper motor oil as suggested in the Table below.

Season or Temperature Spring, Summer or Autumn + 120° F to +15° F Winter + 40° F to +15° F Below +15° F	Grade of motor oil (higher than MS class) SAE 30 SAE 30 SAE 10w-30

4.3 INSPECTION

- 1 Check all nuts, bolts fasteners for tightness. Retighten as necessary.
- . Clean any dirt from the recoil starter and foot pedestal. Wipe the entire unit clean before operating.
- 3 Replace any missing or damage Safety Operations decals.
- . Adjust height of handle. Adjust handle by loosening nuts and moving handle to suit operation.
- 4 Retighten nuts.
- .

4.4 START

1. Open the fuel shut-off valve by moving the fuel cock lever to the OPEN position (Fig 5) then set the engine start/stop switch (Fig 5) to the START position.




Fig 5

2. Set the engine ON/OFF switch (Fig 6) to the ON position (start).




Fig 6

3. Close the choke lever (Fig 7) and move the throttle lever to the Full Open position. Turning the choke lever 90 degrees clockwise closes the choke. In cold weather, start the unit with choke fully closed. In warm weather or when the engine is warm, the unit can be started with choke halfway or completely open.




Fig 7

4. Grip the recoil starter (Fig 8) handle and pull it until you feel a slight resistance. Then pull sharply and quickly. Return the recoil starter handle to the starter case before releasing.





Fig 8

5. If engine fails to start, move the choke lever (Fig 7) to the half open position to avoid flooding.
6. Repeat steps 1 to 4.
- . If the engine does not start after repeated attempts, check the spark plug for excess fuel.
7. Clean and replace the spark plug as needed.
8. To start the vibratory rammer action, move the throttle lever (Fig 9) quickly from IDLE (close) to the FULL OPEN position. DO NOT move the throttle lever slowly as this may cause damage to the clutch or spring. Please be noted that for NEW TYPE throttle lever, get O-ring from manual and accessories bag and fix in the throttle lever as Fig 10.

OLD TYPE



NEW TYPE




Fig 9



Fig 10

CAUTION


1. Make sure that the throttle lever is moved to the FULL OPEN position. Operating the rammer at less than full speeds can result in damage to the clutch springs or foot.
2. The vibratory rammer is designed to run at 4,000 rpm. At optimum rpm the foot hits at the rate of 680 impacts per minute. Increasing throttle speed past factory set rpm does not increase impacts and may damage unit. The rammer is designed to advance while tamping. For faster advance, pull back slightly on the handle so that rear of foot contacts soil first.

4.5 STOP ENGINE

Normal Shutdown

1. Move throttle lever quickly from the FULL OPEN to IDLE position (Fig 11) and run the engine for three minutes at low speed. After the engine cools, turn the engine start/stop switch to the “STOP” position (Figure 6) until engine comes to a complete stop.

OLD TYPE



NEW TYPE




Fig 11

2. Close the fuel shut-off valve by moving the fuel cock lever to the CLOSED position. See Figure 5.

Emergency Shutdown

Move the throttle lever quickly to the IDLE position, and turn the engine START/STOP switch to the STOP position.

V .MAINTENANCE

DAILY

- Thoroughly remove dirt and oil from the engine and control area. Clean or replace the air cleaner elements as necessary. Check and retighten all fasteners as necessary. Check the spring box and bellows for oil leaks. Repair or replace as needed.

WEEKLY

- Remove the fuel filter cap and clean the inside of the fuel tank.
- Remove or clean the filter at the bottom of the tank.
- Remove and clean the spark plug, then adjust the spark gap to 0.02~0.03 inch (0.6~0.7 mm). This unit has electronic ignition, which requires no adjustments.
- Clean air cleaner cover.

200 – 300 HOURS

- Remove the element from the pre-cleaner (Figure 12) at the top of the crankcase (body side) and clean it with cleaning oil (kerosene).




Figure 12 Optional Pre-Cleaner

- Lubricate the top element (yellow) with 2~5cc of engine oil SAE-30. Lubricate bottom element (gray) with 13~15cc of engine oil SAE-30 and completely squeeze out the excess oil from the element before installing. The air cleaner (Figure 13) on the engine side will hardly be contaminated, if it is, however after cleaning the element with kerosene, dip it in mixed oil consisting of 3 parts of gasoline and 1 part of engine oil. Then tightly squeeze outer primary element (sponge) and shake off well the inner secondary element before installing them.




Figure 13 Engine Air Cleaner

200 – 300 HOURS (Oil Bath)

- ☐ Drain oil reservoir on foot housing (Figure 14). Refill with approximately 1000cc of MOBIL ISO VG-46 or other oil with same standard. Oil should be midway in sight glass. Break in oil should be changed after first 50 hours.




Figure 14 Foot Housing Drain Plug

YEARLY

- ☐ Check the fuel line and the oil line regularly for damage and to ensure that there are no leaks.
- ☐ Replace the oil and fuel lines every two years to maintain the performance and flexibility lines.

LONG TERM STORAGE

- ☐ Drain fuel from fuel tank, fuel line and carburetor.
- ☐ Remove spark plug and pour a few drops of motor oil into cylinder. Crank engine 3 to 4 times so that oil reaches all internal parts.
- ☐ Clean exterior with a cloth soaked in clean oil.
- ☐ Store unit covered with plastic sheet in moisture free and dust free location out of direct sunlight.

VI. TROUBLESHOOTING

6.1 ENGINE TROUBLESHOOTING

SYMPTOM	Difficult	POSSIBLE PROBLEM	SOLUTION
to start	Fuel is		
available but		Ignition plug being bridge?	Check ignition system.
spark plug will not		Carbon deposit at ignition?	Clean or replace ignition.
ignite. (Power		Short circuit due to defective	Replace insulators.
available at high		insulators?	Set spark plug gap to the correct gap.
tension cable).		Improper spark gap?	Check stop switch circuit. Replace stop switch if defective.
Fuel is available but			
spark plug will not		Short circuit at stop switch	
ignite. (Power NOT			
available at high		Ignition coil defective?	Replace ignition coil.
tension cable).			
Fuel is available and		Muffler clogged with carbon	Clean or replace muffler.
spark plug ignites		deposits?	
(compression		Fuel in use inadequate	Flush fuel system and replace with fresh
normal).		(water, dust)?	fuel.
		Air Cleaner clogged?	Clean or replace air cleaner.
			Tighten cylinder head bolts or replace
Fuel is available and		Defective cylinder head	head gasket.
spark plug ignites		gasket?	Replace cylinder.
(compression low).		Cylinder worn?	Tighten spark plug
		Spark plug loose?	
Operation not satisfactory			
Not enough power		Air cleaner clogged?	Clean or replace air cleaner.
available		Air in fuel line?	Bleed (remove air) from fuel line.
(compression normal,		Fuel level in carburetor float	Adjust carburetor float.
no misfiring).		chamber improper?	Clean or replace cylinder.
		Carbon deposits in cylinder?	
		Ignition coil defective?	Flush fuel system and replace with fresh
		Ignition plug often shorts?	fuel.
			Clean or replace crankcase.
			Clean or replace muffler.
Not enough power			Clean or replace crankcase.
available			Clean or replace muffler.
(compression normal,			Replace spark plug with correct type
misfiring).			spark plug.
		Fuel in use inadequate	
		(water, dust)?	
Engine overheats.		Combustion chamber?	
		Exhaust or muffler clogged	
		with carbon.	
		Spark plug heat value	
		incorrect?	


SYMPTOM	POSSIBLE PROBLEM	SOLUTION
Rotational speed fluctuates.	Governor adjustment improper?	Adjust governor to correct lever. Clean or replace ignition.
	Governor spring defective?	Check fuel line. Check suction line.
	Fuel flow erratic?	Clean recoil starter assembly.
	Air taken in through suction line?	Replace spiral spring.
Recoil starter not working properly.	Dust in rotating part?	
	Spiral spring failure?	

6.2 RAMMER TROUBLESHOOTING

Engine rotates but does not strike.	Operation speed of throttle lever is incorrectly set?	Set throttle lever to correct position.
	Oil in excess?	Drain excess oil. Bring to correct level.
	Clutch slips?	Replace or adjust clutch.
	Spring failure?	Replace spiral spring.
	Speed of engine improper?	Adjust engine speed to correct operating RPM setting.


VII. REPLACEMENT PARTS LIST

7.1 GUIDE CYLINDER AND FOOT ASSY



PART NO.	DESCRIPTION	QTY
A01	Sunk head bolt 12*75H(Foot Assy without Handle/ with Plastic sleeve)	4
A01	Sunk head bolt 12*105H(Foot Assy with Handle/with	4
A01	Sunk head bolt 12*105H(Foot Assy without	4
A01	Sunk head bolt 12*105H(Foot Assy with Handle/with	4
A02	Sunk head bolt 12*55 H	7
A03	Metal sheet	1
A04	Foot 285B-331L	1
A05	Foot Assy	1
A06	Washer SWφ12	11
A08	Washer SWφ12	7
A09	Nylon nut M12	11
A10	Nut M18,	1
A11	Socket head bolt 10*20T	4
A12	Socket head bolt 10*35T	4
A13	Foot plate	1
A14	Packing 1/4(CU)	1
A15	Plug M12*1.25	1
A19	O-ring G-90	1
A20	Inner spring (for engines except Honda GX100)	2
A20	Inner spring (for Honda GX100)	2
A21	Out spring	2
A22	Spring cylinder	1
A24	Pin φ 16	1
A25	Piston rod kit	1
A26	Stop ring φ 15	1
A27	O-ring G-90	2
A28	Protection sleeve(Plastic)	1
A28	Protection sleeve (Optional Al)	1
A29	Copper packing 17*25.5*1	1
A30	Level gauge, plug type	1
A31	Packing 1/4(CU)	1
A32	Plug M12*1.25	1
A33	O-ring 160*4	1
A34	Bellows clamp	2
A35	Band guide,bellows	2
A36	Socket head bolt M6*50	2
A37	Nut M6	2
A38	Dowel pinφ6×8	1
A39	Bellow (Made in China)	1
A39	Bellow (Made in Germany, optional)	1
A41	Pin 6D-8.5L	
A43	Socket head bolt 10*35T	
A44	Guide cylinder	4
A45	O-ring φ110×4	1
A46	piston end	1
		1


7.2 CRANKCASE AND ENGINE ASSY



PART NO.	DESCRIPTION	QTY
B01	Bolt 6*18H,SW	9
B02	Case cover	1
B03	O-ring 22.4*2.65	1
B04	Hexagonal bolt 8*20	1
B05	Washer M8	1
B06	Internal circlip $\varnothing 50$	1
B07	Bearing6204	1
B08	Connecting rod	1
B09	Gear wheel	1
B10	Internal circlip $\varnothing 62$	1
B11	Bearing6207	1
B12	Bearing6305-2Z	1
B13	Crank case	1
B14	External circlip $\varnothing 20$	1
B15	O-ring 40*2.4	1

PART NO.	DESCRIPTION	QTY
B16	Bearing cover	1
B17	Key 5*20	1
B18	Pinion(for engines except Honda GX100)	1
B18	Pinion(for Honda GX100)	1
B19	Bearing6204	1
B20	Bearing6007	1
B21	Oil seal 40*68*8	1
B22	Clutch drum(for engines except Honda	1
B22	GX120)	1
B23	Clutch drum(for Honda GX120) Washer	1
B24	¢ 8*7 Bolt M 8*25 T Washer SW φ10 Socket	1
B25	head bolt 10*35 Lock washer Clutch assy (4
B26	depends on engines) Woodruff key 4*13	4
B27	Connecting plate, engine(depends on engines)	1
B28	Engine Bottom plate, engine(depends on	1
B29	engines) Bolt M10*50 Bolt M8*40 Washer,	1
B30	SW M8 Washer,8.5*22*3 Nylon nut M8	1
B31	Throttle cable(depends on engines) Throttle	1
B32	lever	1
B33		2
B34		4
B35		4
B36		4
B37		4
B40		1
B43		1

7.3 TANK AND HANDLE ASSY



PART NO.	DESCRIPTION	QTY
C01	Handle(depends on engines)	1
C02	Roller handle	1
C03	Flange bolt 8*25 H	4
C04	Flange nut M5	4
C05	Shock absorber	2
C06--1	Shock head bolt 10*20	4
C06--2	Tooth locked washer BM10	8
C07	Bolt10*20 T	4
C08	Nylon nut M8	2
C09	Washer,φ8*22*3	2
C11	Fuel tank	1
C12	Hexagonal bolt 8*40	2
C13	Fuel tank cap	1
C15	washer,throttle lever	1
C17	Fuel cock assy	1
C18	Hose band 9.5D	2
C19	Hose, fuel	1
C20	Hose band 9.5D	2