

SAVE THIS MANUAL FOR FUTURE REFERENCE

ORIGINAL INSTRUCTION




PLATE COMPACTORS

OPERATOR'S MANUAL

MODEL NUMBER : ☐ CEDZG01

SERIAL NUMBER :

BOTH MODEL NUMBER AND SERIAL NUMBER MAY BE FOUND ON THE MAIN LABEL. YOU SHOULD RECORD BOTH OF THEM IN A SAFE PLACE FOR FUTURE USE.

FOR YOUR SAFETY

**READ AND UNDERSTAND THE ENTIRE MANUAL BEFORE
OPERATING MACHINE**

HAHN
& SOHN
CEDRUS

HAHN A SYN s.r.o.
Lelkova 186/4
747 21 Kravaře
CZECH REPUBLIC
info@hahn-profi.cz

Hahn & Sohn GmbH
Janahof 53
93413 Cham
Deutschland
hahn@hahn-sohn.de

TABLE OF CONTENTS

1	INTRODUCTION	
2	SPECIFICATIONS	
3	SYMBOLS	
4	SAFETY	
5	GENERAL SAFETY RULES	
6	SPECIFIC SAFETY RULES	
	CONTENTS SUPPLIED	
	ASSEMBLY	
	KNOW YOUR COMPACTOR	
10	FEATURES & CONTROLS	
12	COMPACTOR OPERATION	
	MAINTENANCE	
	STORAGE	
	LIFTING/TRANSPORTING	
	TROUBLE SHOOTING	
	PARTS SCHEDULE	

INTRODUCTION

YOUR NEW VIBRATORY PLATE COMPACTOR WILL MORE THAN SATISFY YOUR EXPECTATIONS. IT HAS BEEN MANUFACTURED UNDER STRINGENT QUALITY STANDARDS TO MEET SUPERIOR PERFORMANCE CRITERIA. YOU WILL FIND IT EASY AND SAFE TO OPERATE, AND WITH PROPER CARE, IT WILL GIVE YOU MANY YEARS OF DEPENDABLE SERVICE.



CAREFULLY READ THROUGH THIS ENTIRE OPERATOR'S MANUAL BEFORE USING YOUR NEW LOG SPLITTER. TAKE SPECIAL CARE TO READ THE

THE COMPACTOR HAS BEEN DESIGNED INTO DETAILS: REINFORCED SELF-CLEANING BASE PLATE, ENGINE OIL DRAIN HOSE, CLOSED V-BELT GUARD, SELF-ADJUSTING CENTRIFUGAL CLUTCH AND FOLDING HANDLE. A RANGE OF USEFUL ACCESSORIES ENABLES USE IN ALL KINDS OF APPLICATIONS.

THE PLATE COMPACTOR APPLIES ENERGY TO THE LOOSE SOIL OR OTHER MATERIALS TO INCREASE ITS DENSITY AND LOAD BEARING CAPACITY, MAINLY USED FOR SMALL REPAIR AND MAINTENANCE WORK. THE LOOSE SOIL OR PARTICLES ARE MOVED


OR REARRANGED IN A PARTICULAR MANNER CLOSE TO EACH OTHER TO

AVOID OVERHEATING. IT IS NOT INTENDED TO BE USED ON INCREASED COHESIVE SOILS SUCH AS CLAY OR THE LOAD BEARING CAPACITY. THE REASON FOR THIS IS THAT THE SOIL ALL ENGINE-RELATED ISSUES WITH REDUCED PERFORMANCE, POWER AND EFFICIENCY. SPECIFICATIONS, AND REFER TO THE ENGINE COMPACTOR'S

OPERATOR'S MANUAL, PACKED SEPARATELY WITH THE UNIT, FOR

SPECIFICATIONS

ITEM NO.	CEDZG01
PLATE SIZE	560 X 520 MM
CENTRIFUGAL FORCE	20000 N
EXCITER SPEED	5500 VPM
COMPACTION SPEED	35 CM
TRAVEL SPEED	35 M/MIN
ENGINE	196CC
OPERATION WEIGHT	96 KG



ENVIRONMENTAL



RECYCLE UNWANTED MATERIALS INSTEAD OF DISPOSING OF THEM AS WASTE. ALL TOOLS, HOSES AND PACKAGING SHOULD BE RECYCLED, TAKEN TO THE LOCAL RECYCLING CENTER AND DISPOSED OF IN AN ENVIRONMENTALLY FRIENDLY MANNER.

SYMBOLS

THE RATING PLATE ON YOUR MACHINE MAY SHOW SYMBOLS. THESE REPRESENT IMPORTANT INFORMATION ABOUT THE PRODUCT OR INSTRUCTIONS ON ITS USE.



READ THESE INSTRUCTIONS FOR USE CAREFULLY.



WEAR EYE PROTECTION.
WEAR HEARING PROTECTION.



WEAR PROTECTIVE GLOVES.



WEAR SAFETY FOOTWEAR.



IT IS FORBIDDEN TO REMOVE OR TAMPER WITH THE PROTECTION DEVICES AND SAFETY DEVICES.



KEEP AWAY FROM ROTATING PARTS.



DO NOT TOUCH PARTS WHICH ARE HOT FROM OPERATION. SERIOUS BURNS MAY RESULT.



DO NOT SMOKE OR HAVE OPEN FLAMES.



USE EXTREME CAUTION WHEN STORING, HANDLING AND USING FUELS, AS THEY ARE HIGHLY VOLATILE AND EXPLOSIVE IN VAPOR STATE. KEEP CHILDREN AND BYSTANDERS OFF AND AWAY.

SAFETY

68

GENERAL SAFETY RULES

UNDERSTAND YOUR MACHINE

READ AND UNDERSTAND THE OPERATOR'S MANUAL AND LABELS AFFIXED TO THE MACHINE. LEARN ITS APPLICATION AND LIMITATIONS AS WELL AS THE SPECIFIC POTENTIAL HAZARDS PECULIAR TO IT.

BE THOROUGHLY FAMILIAR WITH THE CONTROLS AND THEIR PROPER OPERATION. KNOW HOW TO STOP THE MACHINE AND DISENGAGE THE CONTROLS QUICKLY.

MAKE SURE TO READ AND UNDERSTAND ALL THE INSTRUCTIONS AND SAFETY PRECAUTIONS AS OUTLINED IN THE ENGINE MANUAL.

NEVER START OR RUN THE ENGINE INSIDE A CLOSED SPACE. EXHAUST FUMES ARE DANGEROUS, WITH CARBON MONOXIDE, AN odorless and deadly gas. OPERATE THIS UNIT ONLY IN A WELL VENTILATED OUTDOOR AREA.

UNDERSTAND HOW TO PROPERLY OPERATE AND MAINTAIN THE MACHINE OR LIGHT.

NEVER OPERATE THE MACHINE WITHOUT GOOD REASON. SAFELY AVOID ACCIDENTAL INJURIES AND/OR PROPERTY DAMAGE. DO NOT OPERATE THE MACHINE WHILE UNDER THE INFLUENCE OF DRUGS, ALCOHOL, OR ANY MEDICATION WHICH COULD AFFECT YOUR ABILITY TO USE IT PROPERLY.

DRESS PROPERLY. WEAR HEAVY LONG PANTS, BOOTS AND GLOVES. DO NOT WEAR LOOSE CLOTHING, SHORT PANTS, JEWELRY OF ANY KIND. SECURE LONG HAIR IF IT IS ABOVE SHOULDER LEVEL. KEEP YOUR HAIR, CLOTHING AND GLOVES AWAY FROM MOVING PARTS. LOOSE CLOTHES, JEWELRY OR LONG HAIR CAN BE CAUGHT IN MOVING PARTS.

CHECK YOUR MACHINE BEFORE STARTING IT. KEEP GUARDS IN PLACE AND IN WORKING ORDER. MAKE SURE ALL NUTS, BOLTS, ETC. ARE SECURELY TIGHTENED.

NEVER OPERATE THE MACHINE WHEN IT IS IN NEED OF REPAIR OR IS IN POOR MECHANICAL CONDITION. REPLACE DAMAGED, MISSING OR FAILED PARTS BEFORE USING IT. CHECK FOR FUEL LEAKS. KEEP THE MACHINE IN SAFE WORKING CONDITION.

DO NOT USE THE MACHINE IF THE ENGINE'S SWITCH DOES NOT TURN IT ON OR OFF. ANY GASOLINE POWERED MACHINE THAT CAN NOT BE CONTROLLED WITH THE ENGINE SWITCH IS DANGEROUS AND MUST BE REPLACED.

FORM A HABIT OF CHECKING TO SEE

THAT KEYS

REMOVED FROM WRENCHES ARE MACHINE AREA BEFORE STARTING IT. A

WRENCH OR

A KEY THAT IS LEFT ATTACHED TO A

THE MACHINE MAY RESULT IN PERSONAL INJURY.

STAY ALERT, WATCH WHAT YOU ARE DOING AND USE COMMON SENSE WHEN OPERATING THE MACHINE.

DO NOT OVERREACH. DO NOT OPERATE THE

MACHINE

WHILE BAREFOOT OR WHEN WEARING

SIMILAR LIGHTWEIGHT FOOTWEAR.

WEAR PROTECTIVE

SHOES THAT WILL PROTECT IMPROVE YOUR FOOTING ON SLIPPERY

SURFACES.

KEEP PROPER FOOTING AND BALANCE AT

THIS ENABLES BETTER CONTROL OF THE

MACHINE IN

UNEXPECTED SITUATIONS.

AVOID ACCIDENTAL STARTING. BE SURE

THE ENGINE'S

SWITCH IS OFF BEFORE TRANSPORTING

OR PERFORMING ANY MAINTENANCE

OR SERVICE

ON THE UNIT. TRANSPORTING OR

MAINTENANCE OR SERVICE ON A

MACHINE WITH ITS

SWITCH ON INVITES ACCIDENTS.

FUEL SAFETY FUEL IS HIGHLY

FLAMMABLE, AND ITS VAPORS CAN

EXPLODE IF IGNITED. TAKE

PRECAUTIONS WHEN USING TO REDUCE

THE CHANCE OF SERIOUS PERSONAL

INJURY.

PLATE COMPACTOR

WHEN REFILLING OR DRAINING THE

FUEL TANK, USE

AN APPROVED FUEL STORAGE

CONTAINER WHILE IN A CLEAN, WELL-VENTILATED OUTDOOR

NEVER OVERFILL FUEL TANK (THERE SHOULD BE NO FUEL ABOVE THE UPPER LIMIT MARK).

REPLACE ALL FUEL TANK AND

CONTAINER CAPS

SECURELY AND WIPE UP SPILLED

OPERATE THE UNIT WITHOUT THE FUEL

CAP SECURELY

IN PLACE.

REPLACE ALL FUEL TANK AND

CONTAINER CAPS

SECURELY AND WIPE UP SPILLED

OPERATE THE UNIT WITHOUT THE FUEL

CAP SECURELY

IN PLACE.

AVOID CREATING A SOURCE OF

IGNITION FOR SPILLED

FUEL IF FUEL IS SPILLED, DO NOT

THE ENGINE BUT MOVE THE

MACHINE AWAY

FROM THE AREA OF SPILLAGE AND

ANY SOURCE OF IGNITION UNTIL FUEL

VAPORS HAVE

DISSIPATED.

NEVER PICKUP OR DERRYCONNERS

WHILE THE ENGINE IS RUNNING.

SPECIFICALLY DESIGNED DO NOT FORCE THE MACHINE. USE THE AND APPROVED FOR THIS PURPOSE.

STORAGE FUEL IN A COOL, WELL-

MACHINE FOR YOUR APPLICATION.

VENTILATED AREA, MACHINE WILL DO THE JOB BETTER AND

FLAMES OR OTHER

SOURCE OF IGNITION.

RATE FOR WHICH IT WAS DESIGNED.

NEVER STORE FUEL OR MACHINE WITH

DO NOT CHANGE THE ENGINE GOVERNOR

FUEL IN THE

TANK INSIDE A BUILDING WHERE FUMES

MAY REACH

OR OVERSPEED THE ENGINE. THE

SOURCE THE MAXIMUM SAFE

OF IGNITION, SUCH AS A WATER

RECKING, ETC.

OF THE ENGINE AND THE LIKE. ALLOW

OR RUN THE ENGINE AT A HIGH

COOL BEFORE STORING IN ANY

DO NOT PUT HANDS OR FEET NEAR


ROTATING PARTS.

AVOID CONTACT WITH HOT FUEL, OIL,

EXHAUST FUMES AND HOT SURFACES. DO

NOT TOUCH THE ENGINE OR MUFFLER.

THOSE PARTS CAN EXHAUST FUEL FROM



IF THE MACHINE SHOULD START TO MAKE AN UNUSUAL NOISE OR VIBRATION, IMMEDIATELY SHUT OFF THE ENGINE, DISCONNECT THE SPARK PLUG WIRE, AND CHECK FOR THE CAUSE. UNUSUAL NOISE OR VIBRATION IS GENERALLY WARNING OF TROUBLE.

USE ONLY ATTACHMENTS AND ACCESSORIES APPROVED BY THE MANUFACTURER. SO CAN RESULT IN PERSONAL INJURY.

MAINTAIN THE MACHINE. CHECK FOR MISALIGNMENT OR BINDING OF MOVING PARTS, BREAKAGE OF PARTS AND ANY OTHER CONDITION THAT MAY AFFECT THE MACHINE'S OPERATION. IF DAMAGED, HAVE THE MACHINE REPAIRED BEFORE USE. MANY ACCIDENTS ARE CAUSED BY POORLY MAINTAINED EQUIPMENT.

KEEP THE ENGINE AND MUFFLER FREE OF GRASS, LEAVES, EXCESSIVE GREASE OR CARBON BUILD-UP TO REDUCE THE CHANCE OF A FIRE HAZARD.

NEVER DOUSE OR SQUIRT THE UNIT WITH WATER. BEFORE CLEANING, REPAIR, INSPECTING, OR MAINTENANCE, SHUT OFF HAND LEVER, AND CERTAIN ALL MOVING PARTS ARE STOPPED. BEFORE CLEANING, ENGINE'S SWITCH IS IN ITS "OFF" POSITION. DISCONNECT THE SPARK PLUG WIRE, AND KEEP THE WIRE AWAY FROM THE PLUG TO PREVENT ACCIDENTAL STARTING. OIL, ETC. TO PROTECT THE ENVIRONMENT. HAVE YOUR MACHINE SERVICED BY A

QUALIFIED REPAIR PERSONNEL USING ONLY ORIGINAL PARTS. ALWAYS FOLLOW THE INSTRUCTIONS OF THESE INSTRUCTIONS TO AVOID INJURY. KEEP HANDS, FEET AND FEEL AWAY FROM THE MOVING PARTS. GRIP THE HANDLE OF THE MACHINE FIRMLY WITH BOTH HANDS. IF BOTH HANDS ARE HOLDING THE HANDLE AND YOUR FEET ARE CLEAR OF THE COMPACTOR BASE, YOUR HANDS, FINGERS AND FEET CAN NOT BE INJURED BY THE COMPACTOR BASE.

ALWAYS OPERATE THE MACHINE FROM BEHIND, NEVER PASS OR STAND IN FRONT OF THE MACHINE WHEN THE ENGINE IS RUNNING.

NEVER PLACE TOOLS OR ANY OTHER ITEM UNDER THE PLATE COMPACTOR.

IF THE UNIT STRIKES A FOREIGN OBJECT, STOP THE ENGINE, DISCONNECT THE SPARK PLUG, INSPECT THE MACHINE FOR ANY DAMAGE, AND REPAIR THE DAMAGE BEFORE OPERATING THE MACHINE.

DO NOT OVERLOAD THE MACHINE CAPACITY BY COMPACTING TOO DEEP IN A SINGLE PASS OR AT TOO FAST A RATE.

NEVER OPERATE THE UNIT AT HIGH SPEEDS ON HARD OR SLIPPERY SURFACES. EXERCISE EXTREME CAUTION WHEN OPERATING ON ROADS, GRAVEL DRIVES, WALKS, OR ALERT FOR HIDDEN HAZARDS OR TRAFFIC.

DO NOT CARRY PASSENGERS. NEVER LEAVE THE OPERATING POSITION

AND LEAVE THE PLATE COMPACTOR UNATTENDED WHEN THE ENGINE IS RUNNING.

ALWAYS STOP THE ENGINE WHEN COMPACTING IS DELAYED OR WHEN WALKING FROM ONE LOCATION TO ANOTHER.

STAY AWAY FROM THE EDGED OF DITCHES AND AVOID ACTIONS THAT MAY CAUSE COMPACTOR TO TOPPLE OVER.


ALWAYS ASCEND SLOPES CAREFULLY, IN A DIRECT PATH AND IN REVERSE TO PRESENT THE PLATE COMPACTOR FROM TOPPLING OVER ONTO THE OPERATOR.

ALWAYS PARK THE UNIT ON A FIRM


CONTENTS SUPPLIED

THE PLATE COMPACTOR COMES PARTIALLY ASSEMBLED AND IS SHIPPED IN CAREFULLY PACKED CARTON. AFTER ALL THE PARTS HAVE BEEN REMOVED FROM THE CARTON, YOU SHOULD HAVE:



BASIC MODELS



COMPACTOR WITH OPTIONAL WATER SPRAY SYSTEM



29640



1. PLATE COMPACTOR CHASSIS WITH ENGINE AND TRANSMISSION

2. HANDLE

3. UPPER HANDLE (#29640 ONLY)


4. PAVING PAD (OPTIONAL)

5. FOLDING WHEELS BRACKET (OPTIONAL)

6. WHEELS (OPTIONAL)

7. OPERATOR'S MANUAL & ENGINE MANUAL

8. HARDWARE BAG, INCLUDING






ASSEMBLY

FOLLOWING THE ASSEMBLY DIRECTIONS BELOW, YOU WILL ASSEMBLE THE PLATE COMPACTOR IN A FEW MINUTES.


HANDLE

29642 / 29655 / 29660 / 29665




MOUNT THE HANDLE TO THE CHASSIS WITH THE M10X90 BOLT, WASHERS AND NUT.

29640




1. TURN OVER THE LOWER HANDLE.



2. MOUNT THE UPPER HANDLE TO THE LOWER HANDLE WITH 2 M8X55 BOLTS, WASHERS AND NUTS.

THROTTLE CONTROL



UNSCREW BOLT 5X35 FROM THROTTLE CONTROL. SECURE THE THROTTLE CONTROL ONTO THE UPPER HANDLE WITH A FLAT WASHER 5 AND THE BOLT 5X35 THAT JUST WERE UNSCREWED.

FOLDING WHEELS KIT (OPTIONAL)





PLATE COMPACTOR


68

7

1. SLIDE THE WHEELS OVER THE STUB AXLES. SECURE WITH HAIRPIN RETAINERS AND FLAT WASHERS.




2. THREE HOLES ON THE STUB AXLE ALLOW TO ADJUST THE DISTANCE BETWEEN THE WHEELS, PULL OUT THE PIN FIRST, ADJUST THE WHEELS TO THE SUITABLE DISTANCE, THEN TIGHTEN WITH THE PIN.



3. PULL UP THE SPRING BOLT AND PUT THE URAGINE OIL PIPE OF THE WHEELS BRACKET INTO THE MOUNTING BRACKET. ALIGN TWO ENDS OF THE PIPE WITH THE HOLES. SLIDE THE BOLT IN AND SECURE WITH THE CLIPS.

PAVING PAD KIT (OPTIONAL)

THE TRANSPARENT RUBBER PAVING PAD ALLOWS TO COMPACT CONCRETE PAVING SLABS, STONES, BRICKS AND BLOCKS SILENTLY AND GENTLY.




ATTACH THE PAVING PAD ONTO THE BASE PLATE AS SHOWN. ALIGN THE HOLES IN THE BASE PLATE, PAVING PAD AND CLAMP PLATES, AND SECURE IT WITH 3 BOLTS M10X25 AND LOCK WASHERS. (ONLY 2 BOLTS AND LOCK WASHERS FOR #29640.)



FAILURE TO FILL ENGINE SUMP WITH OIL BEFORE STARTING ENGINE WILL RESULT IN PERMANENT DAMAGE AND VOID ENGINE WARRANTY.


ADD OIL ACCORDING TO THE ENGINE MANUAL PACKED SEPARATELY WITH YOUR TILLER.



KNOW YOUR MACHINE

FEATURES AND CONTROLS

68



FUEL VALVE CONTROL THE FUEL VALVE OPENS AND CLOSES THE PASSAGE BETWEEN THE FUEL TANK AND THE CARBURETOR. THE FUEL VALVE LEVER MUST BE IN THE ON POSITION FOR THE ENGINE TO RUN. WHEN THE ENGINE IS NOT IN USE, LEAVE THE FUEL VALVE LEVER IN THE OFF POSITION TO PREVENT CARBURETOR FLOODING AND TO REDUCE THE POSSIBILITY OF FUEL LEAKAGE.

THROTTLE CONTROL THE THROTTLE LEVER CONTROLS ENGINE SPEED. MOVING THE THROTTLE LEVER MAKES THE ENGINE RUN FASTER OR SLOWER.

ENGINE SWITCH THE ENGINE SWITCH ENABLES AND DISABLES THE IGNITION SYSTEM. THE ENGINE SWITCH MUST BE IN THE ON POSITION FOR THE ENGINE TO RUN. TURNING THE ENGINE SWITCH TO THE OFF POSITION STOPS THE ENGINE.


CHOKE LEVER THE CHOKE LEVER OPENS AND CLOSES THE CHOKE VALVE IN THE CARBURETOR. THE CLOSED POSITION ENRICHES THE FUEL MIXTURE FOR STARTING A COLD ENGINE. THE OPEN POSITION PROVIDES THE CORRECT FUEL MIXTURE FOR OPERATION AFTER STARTING, AND FOR RESTARTING A WARM ENGINE. SOME ENGINE APPLICATIONS USE A REMOTELY-MOUNTED CHOKE CONTROL RATHER THAN THE ENGINE-MOUNTED CHOKE LEVER.

RECOIL STARTER GRIP

PULLING THE STARTER GRIP OPERATES THE RECOIL STARTER TO CRANK THE ENGINE.

PLATE COMPACTOR

9



RUNNING THE ENGINE WITH DIRTY OIL CAN CAUSE PREMATURE ENGINE WEAR AND FAILURE. CHANGING OIL REGULARLY IS EXTREMELY IMPORTANT. THE FLEXIBLE OIL DRAIN HOSE IS EQUIPPED TO DRAIN OIL INTO APPROPRIATE RECEPTACLE.

RUNNING THE ENGINE WITH DIRTY OIL CAN CAUSE PREMATURE ENGINE WEAR AND FAILURE. CHANGING OIL REGULARLY IS EXTREMELY IMPORTANT. THE FLEXIBLE OIL DRAIN HOSE IS EQUIPPED TO DRAIN OIL INTO APPROPRIATE RECEPTACLE.

AN ECCENTRIC WEIGHT MOUNTED ON THE EXCITER SHAFT CONTAINED WITHIN EXCITER HOUSING IS DRIVEN AT HIGH SPEED BY A CLUTCH AND BELT DRIVE SYSTEM. THIS HIGH SPEED SHAFT REVOLUTION CAUSES THE RAPID LIFTING AND DOWNWARD RAMMING MOTION OF THE MACHINE AS WELL AS IMPARTING A FORWARD MOTION.

COMPACTOR OPERATION

ADDING FUEL

FILL THE FUEL TANK AS INSTRUCTED IN THE SEPARATE ENGINE MANUAL PACKED WITH THE PLATE COMPACTOR.

MORE DETAILED DESCRIPTION OF THE ENGINE

PRECAUTIONS AND ALL RELATED PROCEDURES CAN BE FOUND IN THE STARTING ENGINE

ENGINE MANUAL
1. MOVE THE FUEL VALVE LEVER TO THE ON POSITION.
PACKED SEPARATELY WITH THE UNIT.

2. TO START A COLD ENGINE, MOVE THE CHOKE TO THE CLOSE POSITION.

TO RESTART A WARM ENGINE, LEAVE THE CHOKE LEVER IN THE OPEN POSITION.

3. MOVE THE THROTTLE LEVER AWAY FROM THE SLOW POSITION, ABOUT 1/3 OF THE WAY TOWARD THE FAST POSITION.

4. TURN THE ENGINE SWITCH TO THE ON POSITION.

5. OPERATE THE STARTER.

OPERATING



DO NOT OPERATE PLATE ON CONCRETE OR ON EXTREMELY HARD, DRY, COMPACTED SURFACES. THE PLATE WILL JUMP RATHER THAN VIBRATE AND COULD DAMAGE BOTH PLATE AND ENGINE.

1. AFTER ENGINE WARMS UP, PULL THROTTLE LEVER TO ACCELERATE ENGINE SPEED. PLATE WILL BEGIN VIBRATING AND MOVE FORWARD.

2. THE PLATE COMPACTOR IS

DESIGNED TO

RUN AT AN ENGINE SPEED (ENGINE SHAFT) OF 3600 RPM (NORMALLY

CONSIDERED

ENGINE SPEED). RUNNING THE LOWER RPM'S WILL RESULT IN A

DECREASE OF


COMPACTION FORCE AND LOWER

IT WILL CREATE EXCESSIVE "OUT-

OF-SYNCH"

VIBRATIONS, RESULTING IN POOR


MANEUVERABILITY, EXCESSIVE




3. IN OPERATION, GUIDE THE MACHINE, BUT LET THE COMPACTOR DO THE WORK. BEARING DOWN ON THE HANDLE IS UNNECESSARY AND CAUSES SHOCK ABSORBER WEAR.


4. ON LEVEL SURFACES THE COMPACTOR MOVES FORWARD RAPIDLY. ON UNEVEN SURFACES OR INCLINES, LIGHT FORWARD PRESSURE ON HANDLE MAY BE REQUIRED TO ASSIST THE COMPACTOR IN MOVING FORWARD.

5. THE NUMBER OF PASSES REQUIRED TO REACH A DESIRED COMPACTION LEVEL WILL DEPEND ON THE TYPE AND MOISTURE CONTENT OF SOIL. MAXIMUM SOIL COMPACTION HAS BEEN REACHED WHEN EXCESSIVE KICKBACK IS NOTICED.

 WHEN USING A COMPACTOR ON ASPHALT, WATER SPRINKLER KIT IS REQUIRED TO HELP PREVENT THE BOTTOM PLATE FROM ADHERING TO THE HOT ASPHALT SURFACE.

 WHEN USING PLATE ON PAVING STONES, REMOVE PAD TO THE PLATE TO PREVENT

CHIPPING OR SCOURING SURFACE OF THE SPECIAL URETHANE PAD DESIGNED FOR THIS PURPOSE IS AVAILABLE AS AN OPTIONAL ACCESSORY.

 WHILE A CERTAIN AMOUNT OF MOISTURE IN THE SOIL IS NECESSARY, EXCESSIVE MOISTURE MAY CAUSE SOIL PARTICLES TO STICK TOGETHER AND PREVENT GOOD COMPACTION. IF SOIL IS EXTREMELY WET, ALLOW IT TO DRY SOMEWHAT BEFORE COMPACTING.

IF SOIL IS SO DRY AS TO CREATE DUST CLOUDS WHILE OPERATING PLATE, SOME MOISTURE SHOULD BE ADDED TO THE GROUND MATERIAL TO IMPROVE

STOPPING ENGINE

TO STOP THE ENGINE IN AN EMERGENCY, SIMPLY TURN THE ENGINE SWITCH TO THE OFF POSITION. UNDER

NORMAL CONDITIONS, USE THE FOLLOWING PROCEDURE.

1. MOVE THE THROTTLE LEVER TO THE SLOW POSITION.

2. LET ENGINE IDLE FOR ONE OR TWO MINUTES.

3. TURN THE ENGINE SWITCH TO THE OFF POSITION.

4. TURN THE FUEL VALVE LEVER TO THE OFF POSITION.

 DO NOT MOVE CHOKE CONTROL TO CLOSE TO STOP ENGINE. BACKFIRE OR ENGINE DAMAGE MAY OCCUR.

IDLE SPEED

SET THROTTLE CONTROL LEVER TO ITS "LOW" POSITION TO REDUCE STRESS ON THE ENGINE WHEN COMPACTING IS NOT BEING PERFORMED. LOWERING THE ENGINE SPEED TO IDLE THE ENGINE WILL HELP EXTEND THE LIFE OF THE ENGINE, AS WELL AS CONSERVE FUEL AND REDUCE THE NOISE LEVEL OF THE MACHINE.

MAINTENANCE

MAINTAINING YOUR COMPACTOR WILL INSURE LONG LIFE TO THE MACHINE AND ITS COMPONENTS.

PREVENTIVE MAINTENANCE

1. TURN OFF ENGINE. ENGINE MUST BE COOL.
2. COOL. KEEP THE ENGINE'S THROTTLE LEVER IN ITS SLOW POSITION, AND REMOVE SPARK PLUG

3. WIRE FROM SPARK PLUG AND SECURE.

INSPECT THE GENERAL CONDITION OF THE

PLATE COMPACTOR. CHECK FOR LOOSE SCREWS,

MISALIGNMENT OR BINDING OF

4. REMOVE ALL DEBRIS FROM THE PLATE COMPACTOR WITH A SOFT BRUSH, VACUUM, OR COMPRESSED AIR. THEN USE A PREMIUM

QUALITY LUBRICANT ON ALL MOVING PARTS.

AFFECT ITS SAFE

5. CLEAN THE BOTTOM OF THE COMPACTOR BASE. PROPER ADJUSTMENT WILL ASSURE LONG BELT LIFE. AS SOON AS IT BEGINS TO PICK UP SOIL, STOP. TOO MUCH OR TOO LITTLE BELT TENSION WILL CAUSE PREMATURE BELT FAILURE. JOB IF THE BOTTOM SURFACE IS NOT SMOOTH AND CLEAN.

6. REPLACE SPARK PLUG WIRE.



NEVER USE A "PRESSURE WASHER" TO CLEAN YOUR PLATE COMPACTOR. WATER CAN PENETRATE TIGHT AREAS OF THE UNIT AND CAUSE DAMAGE TO SPINDLES, PULLEYS, BEARINGS, OR THE ENGINE. THE USE OF PRESSURE WASHERS WILL RESULT IN SHORTENED LIFE AND REDUCE SERVICEABILITY.

CHECKING V-BELT

TO ENSURE OPTIMUM POWER TRANSMISSION FROM THE ENGINE TO THE ECCENTRIC SHAFT, THE V-BELT MUST BE IN GOOD CONDITION AND OPERATE UNDER PROPER TENSION.

1. TURN OFF ENGINE. ENGINE MUST BE COOL.

2. REMOVE THE BELT GUARD TO ACCESS THE V-BELT

CHECK THE CONDITION OF THE V-BELT. IF ANY V-BELT IS CRACKED, FRAYED, OR GLAZED, IT SHOULD BE REPLACED AS SOON AS CONVENIENT.

4. CHECK THE V-BELT TENSION BY SQUEEZING THEM IN THE CENTER. THE NORMAL DEFLECTION ON EACH SIDE SHOULD BE 9MM (3/8" TO 13MM (1/2" WITH MODERATE PRESSURE FROM YOUR THUMB OR FINGER.




ON NEW MACHINES OR AFTER INSTALLING A NEW BELT, CHECK BELT TENSION AFTER FIRST 20 HOURS OF OPERATION. CHECK AND ADJUST BELT EVERY 50 HOURS THEREAFTER.


TENSIONING V-BELT

BELT TENSION IS CRITICAL TO GOOD PERFORMANCE.


COMPACTOR WITH OPTIONAL WATER SPRINKLER KIT



1. IF THE PLATE COMPACTOR YOU BOUGHT IS WITH WATER TANK, PLEASE PULL THE WATER TANK UP FROM THE CHASSIS AS SHOWN.




29660



or



2. LOOSEN THE JAM NUTS B, LEAVING ENOUGH SPACE BETWEEN THE NUT AND BRACKET.



3. PUSH ENGINE TOWARD THE BACK OF THE PLATE BY TURNING THE ADJUSTMENT BOLTS A TO REMOVE ANY SLACK IN V-BELT.



WHEN ADJUSTING THE BELT, MAKE SURE THAT THE CLUTCH PULLEY IS IN ALIGNMENT WITH EXCITER PULLEY.

4. WHEN THE V-BELT TENSION IS CORRECT, TIGHTEN THE JAM NUTS B AGAINST THE BRACKET.
5. TIGHTEN THE ENGINE MOUNT BOLTS.
6. REPLACE THE BELT GUARD.




IF THE ADJUSTMENT BOLTS HAVE NO MORE ADJUSTMENT LEFT, THE BELT MAY HAVE TO BE REPLACED.

REPLACING V-BELT

1. LOOSE 4 ENGINE MOUNT BOLTS (DO NOT REMOVE) ONLY ENOUGH TO MOVE THE ENGINE FORWARD.
2. LOOSEN THE JAM NUTS B AND BOLTS A

SHOWN

IN ABOVE FIGURE.



68

PLATE COMPACTOR

13

3. SLIDE THE ENGINE TOWARD THE FRONT OF PLATE AND SLIP THE OLD V-BELT OFF OF THE WHEEL PULLEY AND INSTALL THE NEW V-BELT IN THEIR PLACE.

POSITION THE V-BELT OVER THE ENGINE PULLEY.

5. MOVE THE ENGINE BACK.



WHEN ADJUSTING THE BELT, MAKE SURE THAT THE CLUTCH PULLEY IS IN ALIGNMENT WITH EXCITER PULLEY.

6. WHEN THE V-BELT TENSION IS CORRECT, TIGHTEN THE JAM NUTS B AND THE ENGINE MOUNT BOLTS.

7. REPLACE THE BELT GUARD.



WHEN REMOVING OR INSTALLING THE DRIVE BELT, BE CAREFUL NOT TO GET YOUR FINGERS CAUGHT BETWEEN THE BELT AND PULLEY.


EXCITER LUBRICATION THE EXCITER HOUSING IS PRE-SERVICED USING AUTOMATIC TRANSMISSION FLUID DEXTRON III, MERCON, EXXON (ESSO) NUTO H-32 OR ITS EQUIVALENT. CHANGE FLUID AFTER 200 HOURS OF OPERATION.

1. LET EXCITER COOL BEFORE CHANGING EXCITER OIL.

BASIC MODELS



COMPACTOR WITH OPTIONAL WATER SPRINKLER KIT




2 REMOVE THE BELT GUARD AND V-BELT.

REMOVE THE BOLTS THAT HOLD THE DECK TO THE HOUSING.



3 LIFT ENTIRE DECK WITH ENGINE FROM HOUSING.

.



5. REMOVE PIPE PLUG FROM TOP OF EXCITER HOUSING. TILT HOUSING UPSIDE DOWN SO OIL DRAINS FROM EXCITER. EXAMINE OIL FOR METAL CHIPS AS A PRECAUTION TO FUTURE PROBLEMS.

RETURN PLATE HOUSING TO THE UPRIGHT POSITION.



7. FILL THE EXCITER HOUSING WITH EXCITER OIL.

DO NOT OVERFILL
OVERFILLING CAN RESULT
IN EXCESSIVE
TEMPERATURES IN THE
EXCITER.

8. APPLY PIPE SEALANT TO PIPE PLUG AND REINSTALL INTO TOP OF EXCITER HOUSING.

9. REINSTALL DECK, V-BELT AND BELT GUARD.

ENGINE MAINTENANCE

REFER TO ~~ENGINE MANUAL~~ YOUR
PLATE COMPACTOR FOR THE
INFORMATION ON ENGINE MAINTENANCE.
YOUR ENGINE MANUAL PROVIDES
DETAILED INFORMATION FOR
PERFORMING THE TASKS.

STORAGE

68

IF THE PLATE COMPACTOR WILL NOT BE USED FOR A PERIOD LONGER THAN 30 DAYS, FOLLOWING THE STEPS BELOW TO PREPARE YOUR UNIT FOR STORAGE.

1. DRAIN THE FUEL TANK COMPLETELY. STORED FUEL CONTAINING ETHANOL OR MTBE CAN START TO GO STALE IN 30 DAYS. STALE FUEL HAS HIGH GUM CONTENT AND CAN CLOG THE CARBURETOR AND RESTRICT FUEL FLOW.

2. START THE ENGINE AND ALLOW IT TO RUN UNTIL IT STOPS. THIS ENSURES NO FUEL IS LEFT IN THE CARBURETOR. RUN THE ENGINE UNTIL IT STOPS. THIS HELPS PREVENT DEPOSITS FROM FORMING INSIDE THE CARBURETOR AND POSSIBLE ENGINE DAMAGE.

3. WHILE THE ENGINE IS STILL WARM, DRAIN THE OIL FROM THE ENGINE. REFILL WITH FRESH OIL OF THE GRADE RECOMMENDED IN THE ENGINE MANUAL.

4. ALLOW THE ENGINE TO COOL. REMOVE THE SPARK PLUG AND PUT 60 ML OF SAE-30 OF HIGH QUALITY MOTOR OIL INTO THE CYLINDER. PULL THE STARTER ROPE SLOWLY TO DISTRIBUTE THE OIL. REPLACE THE SPARK PLUG.




REMOVE THE SPARK PLUG AND DRAIN ALL OF THE OIL FROM THE CYLINDER BEFORE ATTEMPTING TO START THE UNIT AFTER STORAGE.


5. USE CLEAN CLOTHS TO CLEAN OFF THE OUTSIDE OF THE COMPACTOR AND TO KEEP THE AIR VENTS FREE OF OBSTRUCTIONS.



DO NOT USE STRONG DETERGENTS OR PETROLEUM BASED CLEANERS WHEN CLEANING PLASTIC PARTS. CHEMICALS CAN DAMAGE PLASTICS.



5. PULL UP THE SPRING BOLT AND FOLD UP THE WHEELS BRACKET.




6. CAREFULLY FOLD THE ? HANDLE DOWN. DO NOT ALLOW CONTROL CABLES TO BECOME PINCHED OR BENT.

7. STORE YOUR PLATE COMPACTOR IN UPRIGHT POSITION IN A CLEAN, DRY BUILDING THAT HAS GOOD VENTILATION.

LIFTING/TRANSPORTING

SEE TECHNICAL DATA FOR THE WEIGHT OF THE MACHINE.


TO AVOID BURNS OR FIRE HAZARDS, LET ENGINE COOL BEFORE LIFTING / TRANSPORTING MACHINE OR STORING INDOORS.



THE UNIT MUST BE TRANSPORTED IN THE UPRIGHT POSITION TO PREVENT FUEL FROM SPILLING. DO NOT LAY MACHINE ON ITS SIDE OR TOP.

SECURE OR TIE DOWN UNIT USING THE LIFTING HANDLE

TO PREVENT MACHINE FROM SLIDING OR TIP MACHINE MAY FALL AND CAUSE OVER. DAMAGE OR INJURY IF LIFTED INCORRECTLY. LIFT USING HANDLES AT BASE OF PLATE.



TROUBLE SHOOTING


68

PROBLEM	CAUSE	REMEDY
ENGINE FAILS TO START.	1.SPARK PLUG WIRE DISCONNECTED. 2.OUT OF FUEL OR STALE FUEL. 3.THROTTLE CONTROL LEVER NOT IN CORRECT STARTING POSITION. 4.CHOKE NOT IN ON POSITION. CHOKE FOR A COLD START. 5.BLOCKED FUEL LINE. 6.FOULED SPARK PLUG. 7.ENGINE FLOODING.	1. ATTACH SPARK PLUG WIRE SECURELY TO SPARK PLUG. 2.FILL WITH CLEAN, FRESH GASOLINE. 3.MOVE THROTTLE CONTROL LEVER TO START POSITION. 4.THROTTLE MUST BE POSITIONED AT 5.CLEAN THE FUEL LINE. 6.CLEAN, ADJUST GAP, OR REPLACE. 7.WAIT A FEW MINUTES TO RESTART, BUT DO NOT PRIME.
ENGINE RUNS ERRATICALLY.	1.SPARK PLUG WIRE LOOSE. 2.UNITE RUNNING ON CHOKE. 3.BLOCKED FUEL LINE OR STALE FUEL. 4.VENT PLUGGED. 5.WATER OR DIRT IN FUEL SYSTEM. 6.DIRTY AIR CLEANER.	1.CONNECT AND TIGHTEN SPARK PLUG WIRE. 2.MOVE CHOKE LEVER TO OFF. 3.CLEAN FUEL LINE. FILL TANK WITH CLEAN, FRESH GASOLINE. 4.CLEAR VENT. 5.DRAIN FUEL TANK. REFILL WITH FRESH FUEL. 6.CLEAN OR REPLACE AIR CLEANER.
ENGINE OVERHEATS.	1.ENGINE OIL LEVEL LOW. 2.DIRTY AIR CLEANER. 3.AIR FLOW RESTRICTED.	1.FILL CRANKCASE WITH PROPER OIL. 2.CLEAN AIR CLEANER. 3.REMOVE BLOWER HOUSING AND CLEAN.
ENGINE WILL NOT STOP WHEN THROTTLE CONTROL IS POSITIONED AT STOP OR ENGINE SPEED DOES NOT INCREASE PROPERLY WHEN THROTTLE CONTROL IS ADJUSTED.	1.DIRT IS INTERFERING WITH THROTTLE PACKAGE.	1.CLEAN DIRT AND DEBRIS.
COMPACTOR IS DIFFICULT TO CONTROL WHEN JOLTS OR LURCHES FORWARD)	1.TOO HIGH ENGINE SPEED ON HARD GROUND.	1.HARD SEE THE THROTTLE LEVER AT LOWER SPEED.

PLATE COMPACTOR

17

29640





29642 / 29655 / 29660 / 29665

68




PLATE COMPACTOR


19

PARTS LIST

29640

NO.	DESCRIPTION	Qty
1	WASHER 10	10
2	NUT M10	7
3	LOWER HANDLE	1
4	LOWER OPERATION HANDLE WEEDMOWER	1
5	SHOCK ABSORBER	1
6	BOLT M10X60	2
7	RUBBER SLEEVE	2
8	BOLT M10X90	1
9	TROTTLE LEVER	1
10	WASHER 5	1
11	NUT M10	1
12	BOLT M8X55	2
13	UPPER HANDLE	1
14	ENGINE 2.8HP	1
15	HOSE	1
16	BOLT M8X16	1
17	BOLT M6X25	1
18	BOLT M10X30	2
19	CONNECTOR	1
20	NUT M10	2
21	FLYWEIGHT & FRICTION DISK	4
22	FLYWEIGHT SPRING	2
23	SHAFT FOR CLUTCH PULLEY	1
24	SHOULDER COVER ASSEMBLING PLATE	1
25	WASHER 8	9
26	WASHER 8	4
27	NUT M8	6
28	BOLT M8X25	1
29	BOLT M10X30	2
30	WASHER 10	4
31	SCREW M8X16	1
32	BELT COVER	1
33	SMALL PULLEY PLATE	2
34	BOLT M8X20	

NO.	DESCRIPTION	Qty
35	WASHER 30	1
40	CIRCLIP 25	1
43	CLUTCH PULLEY	1
44	WASHER 30	1
45	BEARING 6006-2RS	1
46	SPRING BOLT	1
47	ENGINE CHASSIS	1
48	ENGINE PAD	1
49		4
44	NUT M6	1
45	BOLT WITH WASHERS M6X20	12
46	BOLT M6X35	1
47	BOLT M8X35	1
48	NUT M8 BOLT	1
49	M8X25	2
50	PULLEY	1
51	BEARING	1
52	WASHER 10	2
53	SCREW FB30X42X6F	1
57	KEY C5X35	1
60	RUBBER ABSORBER	4
12	NUT M6	1
	WASHER 6	1
	KEY C5X35	2
	BOLT M12X30	4
		1
61	BEARING COVER	1
	WASHER 10	1
	G35 PLUG AND	1
		2
65	BEARING 6307	1
66	ECCENTRIC SHAFT	2
67	SCREW M8X25	1
68	PLUG	



29640

NO.	DESCRIPTION	Qty
69	NUT M12	2
70	WASHER	1
71	PROTECTIVE BUSHING	1
72	FELT PLUG	1

OPTIONAL PAVING PAD KIT

NO.	DESCRIPTION	Qty
1*	BOLT M10X25	2
2*	WASHER 10	2
3*	MOUNTING BAR	1
4*	PAVING PAD	1

OPTIONAL FOLDING WHEELS KIT

68

NO.	DESCRIPTION	Qty
5*	SPRING CLIP2	2
6*	WASHER 12	4
7*	WHEEL	2
8	EXTENDED SHAFT	2
*	WHEEL BRACKET	1
10*	BOLT	1
11*	SHAFT B14X100	1
12*	SPRING CLIP1	2
13*	SPRING CLIP3	1

PLATE COMPACTOR


21

NO.	DESCRIPTION	Qty
1	WASHER 10	10
2	NUT M10	7
3	LOWER HANDLE	1
4	NUT M12	2
5	SHOCK ABSORBER	1
6	BOLT M10X60	2
7	RUBBER SLEEVE	2
8	BOLT M10X90	1
9	TROTTLE LEVER	1
10	WASHER 5	1
11	NUT M10	1
1	PLUG	1
2	UPPER HANDLE	1
1	ENGINE 5.5HP	1
3	HOSE	1
1	BOLT M8X16	1
4	BOLT M8X30	1
1	SMALL PULLEY PLATE	1
5	CONNECTOR	1
20	COVER FOR CLUTCH PULLEY	1
21	FLYWEIGHT & FRICTION DISK	2
22	FLYWEIGHT SPRING	2
23	SHAFT FOR CLUTCH PULLEY	1
24	BELT COVER ASSEMBLING PLATE	1
25	WASHER 8	5
26	WASHER 8	5
27	NUT M8	4
28	BOLT M8X25	1
29	WASHER 6	2
30	SCREW M6X12	2
31	SCREW M8X16	4
32	BELT COVER	1
33	SMALL PULLEY PLATE	1

NO.	DESCRIPTION	Qty
34	WASHER	1
35	V-BELT	1
36	CIRCLIP 68	1
37	CLUTCH PULLEY	1
38	CIRCLIP 40	1
39	BEARING 6008-2RS P6	1
40	SCREW M8X25	3
41	ENGINE CHASSIS	1
42	ENGINE PAD	1
43	FLAT WASHER	4
44	NUT M6	1
45	BOLT WITH WASHERS M6X20	12
46	BOLT M6X35	1
47	BOLT M8X35	2
48	NUT M8 BOLT	2
49	M8X40	4
50	PULLEY	1
51	BEARING	1
52	WASHER	2
53	BEARING FB30X42X6F	1
57	KBB BEARING	1
60	RUBBER ABSORBER	4
12	FELT PLUG	1
	WASHER 6	1
	KEY C5X35	1
	BOLT M12X30	2
		4
		1
61	BEARING COVER PLATE	1
	WASHER PLATE	1
	GAS PLUG	1
		2
6	BEARING 6209	1
5	ECCENTRIC SHAFT	1

6

6



OPTIONAL PAVING PAD KIT

NO.	DESCRIPTION	Qty
1*	BOLT M10X25	3
2*	WASHER 10	3
3*	MOUNTING BAR	1
4*	PAVING PAD	1

OPTIONAL FOLDING WHEELS KIT

NO.	DESCRIPTION	Qty
5*	SPRING CLIP2	2
6*	WASHER 12	4
7*	WHEEL	2
8	EXTENDED SHAFT	2
*	WHEEL BRACKET	1
10*	BOLT	1
11*	SHAFT B14X100	1
12*	SPRING CLIP1	2
13*	SPRING CLIP3	1

OPTIONAL WATER SPRINKLER KIT

68

NO.	DESCRIPTION	Qty
14*	TANK CAP	1
15*	WATER TANK	1
16*	OUTLET PIPE	1
17*	HOSE CLAMP D10-16	2
18*	BALL VALVE	1
19*	ELBOW -1/4	1
20*	OUTLET PIPE WELDMENT	1
21*	BOLT M8X20	4
22*	WASHER 8	4
23*	NUT M8	4
24*	WASHER 8	4

PLATE COMPACTOR

