




Lp	Kod	Nazwa	Ilość
1	SP31515A-1	Hopper	1
2	SP31515A-2	Nylon Washer	8
3	SP31515A-3	Inner Hex Bolt M6x45	6
4	SP31515A-4	Open Type Blind Rivet M5x13	4
5	SP31515A-5	Flat Washer Ø5	4
6	SP31515A-6	Open Type Blind Rivet M5x8	2
7	SP31515A-7	Revolving Shaft Sleeve	1
8	SP31515A-8	Fixed Adjustable Plate	1
9	SP31515A-9	Active Adjustable Plate	1
10	SP31515A-10	Torsional Spring Fixed Plate	1
11	SP31515A-11	Hex Bolt M6x16	2
12	SP31515A-12	Connecting Rod Fixed Plate	1
13	SP31515A-13	Hex Lock Nut M6	12
14	SP31515A-14	Installation Tube	1
15	SP31515A-15	Impeller	1
16	SP31515A-16	Wheel	2
17	SP31515A-17	Cotter Pin Ø3x30	2
18	SP31515A-18	Flat Washer Ø16	2
19	SP31515A-19	Oil Cap M6	2
20	SP31515A-20	Hex Lock Nut M8	9
21	SP31515A-21	Hex Wheel Axle Sleeve	2
22	SP31515A-22	Camber Washer	8
23	SP31515A-23	Thin Washer	1
24	SP31515A-24	R Pin	1
25	SP31515A-25	Screw M4X20	1
26	SP31515A-26	Hex Bolt M6x45	3
27	SP31515A-27	Gear Box	1
28	SP31515A-28	Left & Right Support Tube	2
29	SP31515A-29	Square Neck Bolt M8x50	2
30	SP31515A-30	Support Leg	1
31	SP31515A-31	Adjustment Lever	1
32	SP31515A-32	Handle Connecting Tube	1
33	SP31515A-33	Handle Sleeve	2
34	SP31515A-34	Big Flat Washer Ø6	3
35	SP31515A-35	Camber Washer Ø6.5xØ18	2
36	SP31515A-36	Hex Bolt M8x35	1
37	SP31515A-37	Graduated Plate	1
38	SP31515A-38	Spring	1
39	SP31515A-39	Big Flat Washer Ø8	1
40	SP31515A-40	Handle	1
41	SP31515A-41	Adjustable Handle B	1
42	SP31515A-42	Screw M4X18	1
43	SP31515A-43	Adjustable Handle A	1
44	SP31515A-44	Screen	1
45	SP31515A-45	Rain Cover	1
46	SP31515A-46	Hex Bolt M6x20	1
47	SP31515A-47	Torsional Spring	1
48	SP31515A-48	Square Neck Bolt M8x45	6